Legende: ok	Verwendung möglich
NO	Verwendung nicht möglich
XX	Verwendung nicht sinnvoll oder nicht erforderlich
empf	Verwendung empfohlen
incl.	Bestandteil der Option
Erf.	Erforderliche Option
Kennzeichnung bzgl. der Montage von Funktionsbaugruppen	
	nachträgliche Montage ohne Nacharbeit möglich
	nachträgliche Montage nur mit Nacharbeit möglich

Pos.-Nr.	Seite Katalog	Kapitel aus THB	Bezeichnung der Funktionsbaugruppe	Kurzbezeichnung	Artikel-Nr.	1 MA Schutzleiterverdrahtung und Berührungsschutz für gefährl	2 MA ESD-Ausbau	3 MA ESD-Ausbau bei Schutzleiterverdrahtung	4 2-Stufen-Kontaktierung von unten (ohne Selbstöffner)	5 2-Stufen-Kontaktierung unten mit Selbstöffner	6 Sicherheitsschalter mit Zuhaltung NO (stromlos offen)	7 Sicherheitsschalter mit Zuhaltung NC (stromlos geschlossen)	8 Sicherheitsschalter ohne Zuhaltung	9 Magnetischer Sicherheitsschalter	10 MA Selbstöffner Pneumatisch	11 MA Selbstöffner Elektrisch	12 Öffner-Schließer-Automatik e	13 Sicherheits-Kontaktleiste für Ö	14 MA „NDH geschlossen"-Abfrage - Hubschalter	15 MA „NDH geschlossen"-Abfrage - Induktivsensor	16 MA „NDH geschlossen"-Abfrage - Ver.pos. Ind.sensor	17 MA Abfrage ATS verriegelt	18 MA „NDH geschlossen"-Ver. Hubmagnet NC (stromlos geschlo	19 MA „NDH geschlossen"-Ver. Hubmagnet NO (stromlos offen)	20 MA „NDH geschlossen"-Ver. Pneumatisch verriegelt	21 MA „Niederhalter offen"-Verriegelung	22 MA „Niederhalter offen"-Begrenzung	23 MA Gasdruckfedern für die Antriebseinheit (Bausatz)	24 MA Metallgriff klappbar	25 MA Gut- / Schlecht-LED-Anzeige	26 MA Aufnahme Druckt aster	27 MA Ölbremse	28 MA Klemmschutz	29 MA Verlängerte Klinke	30 MA-Steuerbox	31 MA Magnet-Steuerung	32 ATS ESD-Ausführung	33 ATS Hochfrequenz-Ausführun	34 ATS 2-Stufen-Nachrüstsatz (für Kontaktierung von unten)	35 ATS Verstärkungskit für NDH	36 ATS Verstärkungskit für KTE	37 ATS Einlegesperre für Hub 22mm	38 ATS Berührungsschutz für gefährliche Spannungen	39 ATS Aushebeeinheiten	40 ATS Abfrage NDH geschlossen mit zwei GKS	41 ATS Abfrage NDH geschlossen mit Hubschalter	42 ATS Betätiger für 1-Stufen	43 ATS Betätiger für 2-Stufen (Grundgerät)	44 ATS Betätiger für magnetisch	45 ATS Masseplatten für ATS	46 ATS Montagekit Normal Ausb	47 ATS Montagekit ESD Ausbau k
						5.1	5.2	5.3	5.4	5.5	5.6.1	5.6.2	5.6.3	5.6.4	5.7.1	5.7.2	5.8.1	5.8.2	5.9.1	5.9.2	5.9.3	5.10	5.11.1	5.11.2	5.11.3	5.12	5.13	5.15	5.16	5-17	5.18	5.19	5.20	5.21	5.22	5.23	6.1	6.2	7.1	7.2.1	7.2.2	7.3	7.4	7.5	7.6.1	7.6.2	7.7.1	7.7.2	7.7.3	7.8	7.9.1	7.9.2
						68	68	68	68	68	69	69	69	69	70	70	5	6	70	70	70	71	71	71	71	71	71	72	72	72	72	72	72	73	73	73	36 ff.	37 ff.	73	73	73	74	74	74	74	74	74	74	75	75	75	75
1	68	5.1	MA Schutzleiterverdrahtung und Berührungsschutz für gefährli	**FB-SLV-MA**	113081, 112471, 112472, 112473, 112474, 112475	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	NO	ok	ok	ok	ok	Erf.	ok	ok	ok	ok	ok	ok	ok	ok	ok
2	68	5.2	MA ESD-Ausbau	**FB-ESD-MA**	33482, 113915	ok	X	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	empf	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	Erf.
3	68	5.3	MA ESD-Ausbau bei Schutzleiterverdrahtung	**FB-ESD-S-MA**	43597, 113081	ok	NO	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	incl.	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	Erf.	ok	ok	ok	ok	ok	ok	ok	ok	Erf.
4	68	5.4	2-Stufen-Kontaktierung von unten (ohne Selbstöffner)	**FB-2VM-MA**	106834, 106841	ok	ok	ok	X	NO	ok	ok	ok	ok	NO	NO	NO	NO	empf	empf	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	empf	ok	ok	XX	XX	ok	NO	empf	ok	ok	ok	ok	NO	NO	NO	NO	ok	NO	ok	NO	NO
5	68	5.5	2-Stufen-Kontaktierung unten mit Selbstöffner	**FB-2VM-SO**	110515, 110538	ok	ok	ok	NO	X	ok	ok	ok	ok	ok	ok	NO	NO	empf	empf	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	empf	ok	ok	XX	XX	ok	NO	empf	ok	ok	ok	ok	NO	NO	NO	NO	ok	NO	ok	NO	NO
6	69	5.6.1	Sicherheitsschalter mit Zuhaltung NO (stromlos offen)	**FB-SIS-ZSO-MA**	36210	ok	ok	ok	ok	ok	X	NO	NO	XX	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	ok	ok	ok
7	69	5.6.2	Sicherheitsschalter mit Zuhaltung NC (stromlos geschlossen)	**FB-SIS-ZSG-MA**	46020	ok	ok	ok	ok	ok	NO	X	NO	XX	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	ok	ok	ok
8	69	5.6.3	Sicherheitsschalter ohne Zuhaltung	**FB-SIS-MA**	42066	ok	ok	ok	ok	ok	NO	NO	X	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	ok	ok	ok
9	69	5.6.4	Magnetischer Sicherheitsschalter	**FB-SIS-BM-MA**	41560, 41558, 41556, 41553	ok	ok	ok	ok	ok	XX	XX	XX	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	empf	ok	ok	ok
10	70	5.7.1	MA Selbstöffner Pneumatisch	**FB-SOP-MA**	42701, 42700	ok	ok	ok	NO	ok	ok	ok	ok	ok	X	NO	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	ok	ok	ok	incl.	ok	ok	empf	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
11	70	5.7.2	MA Selbstöffner Elektrisch	**FB-SOE-MA**	45220	ok	ok	ok	NO	ok	ok	ok	ok	ok	NO	X	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	incl.	ok	ok	incl.	ok	ok	empf	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
12	5	5.8.1	Öffner-Schließer-Automatik elektrisch	**FB-OSA-E-MA**	113401, 114263, 114445, 114503, 114535	ok	ok	ok	NO	NO	XX	XX	ok	ok	NO	NO	X	ok	XX	XX	XX	ok	NO	NO	NO	NO	NO	ok	ok	ok	ok	NO	ok	NO	XX	XX	ok	ok	NO	ok	ok	ok	ok	ok	ok	ok	ok	NO	ok	ok	ok
13	6	5.8.2	Sicherheits-Kontaktleiste für Öffner-Schließer-Automatik	**FB-SIS-SOA-MA**	113450, 114287, 114316, 114509, 114826	ok	ok	ok	NO	NO	XX	XX	ok	ok	NO	NO	ok	X	XX	XX	XX	ok	NO	NO	NO	NO	NO	ok	ok	ok	ok	NO	ok	NO	XX	XX	ok	ok	NO	ok	ok	ok	ok	ok	ok	ok	ok	NO	ok	ok	ok
14	70	5.9.1	MA „NDH geschlossen"-Abfrage - Hubschalter	**FB-ABF-G-S-MA**	33840	ok	ok	ok	empf	empf	ok	ok	ok	ok	ok	ok	XX	XX	X	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
15	70	5.9.2	MA „NDH geschlossen"-Abfrage - Induktivsensor	**FB-ABF-G-I-MA**	37550	ok	ok	ok	empf	empf	ok	ok	ok	ok	ok	ok	XX	XX	XX	X	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
16	70	5.9.3	MA „NDH geschlossen"-Abfrage - Ver.pos. Ind.sensor	**FB-ABF-V-I-MA**	43625, 46745	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	XX	XX	XX	XX	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
17	71	5.10	MA Abfrage ATS verriegelt	**FB-ABF-V-SKS-MA**	43246	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
18	71	5.11.1	MA „NDH geschlossen"-Ver. Hubmagnet NC (stromlos geschlos	**FB-VER-G-ESG-MA**	32665	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	NO	ok	ok	ok	ok	X	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	NO	empf	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
19	71	5.11.2	MA „NDH geschlossen"-Ver. Hubmagnet NO (stromlos offen)	**FB-VER-G-ESO-MA**	36065	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	NO	ok	ok	ok	ok	XX	X	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
20	71	5.11.3	MA „NDH geschlossen"-Ver. Pneumatisch verriegelt	**FB-VER-G-P-MA**	49270	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	NO	ok	ok	ok	ok	XX	XX	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
21	71	5.12	MA „Niederhalter offen"-Verriegelung	**FB-VER-O-ESO-MA**	43584	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	X	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
22	71	5.13	MA „Niederhalter offen"-Begrenzung	**FB-OBR-MA**	43592	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	XX	X	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
23	72	5.15	MA Gasdruckfedern für die Antriebseinheit (Bausatz)	**FB-GDF-400N-MA**	48730	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
24	72	5.16	MA Metallgriff klappbar	**FB-MGK-MA**	47715	ok	empf	incl.	ok	ok	ok	ok	ok	ok	ok	incl.	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
25	72	5-17	MA Gut- / Schlecht-LED-Anzeige	**FB-LED-MA**	45770, 45996, 45999, 46000	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	ok	ok	ok	empf	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
26	72	5.18	MA Aufnahme Drucktaster	**FB-ADT-MA**	40980	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
27	72	5.19	MA Ölbremse	**FB-OLB-MA**	51770	ok	ok	ok	empf	empf	ok	ok	ok	ok	incl.	incl.	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
28	72	5.20	MA Klemmschutz	**FB-KSG-MA**	29805	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
29	73	5.21	MA Verlängerte Klinke	**FB-VLK-MA**	43763, 44831	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
30	73	5.22	MA-Steuerbox	**FB-STE-UNI-MA**	42703	XX	XX	XX	XX	XX	XX	XX	XX	XX	empf	empf	XX	XX	ok	ok	NO	XX	NO	ok	ok	ok	XX	XX	XX	empf	XX	XX	XX	XX	X	XX	XX	XX	XX	XX	XX	XX	XX	XX	ok	empf	XX	XX	XX	XX	XX
31	73	5.23	MA Magnet-Steuerung	**FB-STE-MAG-MA**	42810	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	empf	ok	XX	ok	XX	XX	XX	XX	XX	XX	XX	XX	X	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX	XX
32	36 ff.	6.1	ATS ESD-Ausführung	**ATS MAxx ../ESD**	46026, 46248, 46236, 46250, 46239, 46254, 46242	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
33	37 ff.	6.2	ATS Hochfrequenz-Ausführung	**ATS MAxx ../HF/AL/ESD**	154011, 154012, 154013, 154014, 154111, 154112, 154113, 154114	NO	ok	ok	NO	NO	NO	NO	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
34	73	7.1	ATS 2-Stufen-Nachrüstsatz (für Kontaktierung von unten)	**FB-2SN-ATS**	48266	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
35	73	7.2.1	ATS Verstärkungskit für NDH	**FB-VSL-NDH-ATS**	46013, 46014, 115006	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
36	73	7.2.2	ATS Verstärkungskit für KTE	**FB-VSL-KTE-ATS**	45719, 46861, 46863, 115008	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
37	74	7.3	ATS Einlegesperre für Hub 22mm	**FB-ELS-22-ATS**	47730	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	X	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok
38	74	7.4	ATS Berührungsschutz für gefährliche Spannungen	**FB-BSP-ATS**	41809, 41811, 41812, 41813, 41814	Erf.	ok	Erf.	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	X	ok	ok	ok	ok	ok	ok	ok	ok	ok
39	74	7.5	ATS Aushebeeinheiten	**FB-AHE-ATS**	42741, (42731)	ok	ok	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	X	ok	ok	ok	ok	ok	ok	ok	ok
40	74	7.6.1	ATS Abfrage NDH geschlossen mit zwei GKS	**FB-ABF-G-GKS-ATS**	46396	ok	ok	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	X	XX	ok	ok	ok	ok	ok	ok
41	74	7.6.2	ATS Abfrage NDH geschlossen mit Hubschalter	**FB-ABF-K-S-ATS**	33510	ok	ok	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	empf	XX	ok	ok	ok	ok	ok	ok	ok	ok	XX	X	ok	ok	ok	ok	ok	ok
42	74	7.7.1	ATS Betätiger für 1-Stufen	**FB-BTV-ATS**	100414, 36455	ok	ok	ok	NO	NO	ok	ok	ok	ok	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	XX	XX	ok	ok	ok
43	75	7.7.2	ATS Betätiger für 2-Stufen (Grundgerät)	**FB-BT2-ATS**	103273, 47740	ok	ok	ok	ok	ok	NO	NO	ok	ok	XX	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	X	XX	ok	ok	ok
44	75	7.7.3	ATS Betätiger für magnetischen Sicherheitsschalter	**FB-BTM-ATS**	41552	ok	ok	ok	NO	NO	XX	XX	XX	XX	empf	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	X	ok	ok	ok
45	75	7.8	ATS Masseplatten für ATS	**MAP-ATSMAxx**	45873, 45874, 45881, 45882, 45883	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	ok	ok
46	75	7.9.1	ATS Montagekit Normal Ausbau Kont. von oben)	**FB-ZSK-ATS**	22652	ok	ok	ok	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X	ok
47	75	7.9.2	ATS Montagekit ESD Ausbau Kont. von oben)	**FB-ZSK-ESD-ATS**	45704	ok	Erf.	Erf.	NO	NO	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	XX	XX	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	ok	X